



Fios
Extender
**USER
GUIDE**



CONTENTS

01/

INTRODUCTION

- 1.0 Package Contents 6
- 1.1 System Requirements 6
- 1.2 Features 6
- 1.3 Getting to Know Your Fios Extender 8

02/

CONNECTING YOUR FIOS EXTENDER

- 2.0 Setting up Your Fios Extender 18
- 2.1 Main Screen 20

03/

WI-FI SETTINGS

- 3.0 Overview 29
- 3.1 Wi-Fi Status 30
- 3.2 Basic Settings 30
- 3.3 Advanced Settings 31
- 3.4 Tri-band Settings 33
- 3.5 Channel Settings 34
- 3.6 Guest Network 37
- 3.7 IoT Network 37

04/

CONFIGURING ADVANCED SETTINGS

- 4.0 Using Advanced Settings 41
- 4.1 Reboot 42
- 4.2 Admin Password 43
- 4.3 Factory Default 44
- 4.4 System Log 45

4.5	Advanced Log	46
4.6	DHCP Log	47
4.7	BHM Log	48

07/ NOTICES

7.0	Regulatory Compliance Notices	69
-----	-------------------------------	----

05/ TROUBLESHOOTING

5.0	Troubleshooting Tips	51
5.1	Frequently Asked Questions	58

06/ SPECIFICATIONS

6.0	General Specifications	64
6.1	LED Indicators	65
6.2	Environmental Parameters	65

01 /

INTRODUCTION

- 1.0** Package Contents
- 1.1** System Requirements
- 1.2** Features
- 1.3** Getting to Know Your Fios Extender

Fios Extender lets you transmit and distribute digital entertainment and information to multiple devices in your office.

Your Extender supports networking using coaxial cables, Ethernet, or Wi-Fi, making it one of the most versatile and powerful Wi-Fi extenders available.

PACKAGE CONTENTS, SYSTEM REQUIREMENTS AND FEATURES

1.0/ PACKAGE CONTENTS

Your package contains:

- Fios Extender
- Power adapter
- OSS (Open Source Software) insert guide

1.1/ SYSTEM REQUIREMENTS

System and software requirements are:

- A computer or other network device supporting Wi-Fi or wired Ethernet
- A web browser, such as Chrome™, Firefox®, Internet Explorer 8® or higher, or Safari® 5.1 or higher

1.2/ FEATURES

Your Fios Extender features include:

- Support for multiple networking standards, including
 - LAN – 802.11 a/b/g/n/ac/ax, Gigabit Ethernet and MoCA 2.5 interfaces

-
- Integrated wired networking with 2-port Ethernet switch and Coax (MoCA LAN)
 - Ethernet supports speeds up to 1000 Mbps
 - MoCA 2.5 LAN enabled to support speeds up to 2500 Mbps over coaxial cable
 - Self-organizing Network (SON) offers seamless roaming, band steering, and AP steering to improve the performance of your Wi-Fi network
 - Integrated Wi-Fi networking with 802.11a/b/g/n/ac/ax access point featuring:
 - Backward compatible to 802.11a/b/g/n/ac
 - 2.4 GHz 11ax 4x4
 - Two 5 GHz 11ax 4x4
 - Enterprise-level security, including:
 - Advanced Wi-Fi protection featuring WPA2 & WPA3 Modes and MAC address filtering
 - Wi-Fi Multimedia (WMM) for Wi-Fi QoS (quality-of-service)
 - Secure remote management using HTTPS


GETTING TO KNOW YOUR FIOS EXTENDER

1.3/ GETTING TO KNOW YOUR FIOS EXTENDER

1.3a/ FRONT PANEL

The front panel's unified button allows quick access to the Wi-Fi Protected Setup (WPS) feature and pairing mode.

The Status LED will be on white and solid when your Fios Extender is turned on, connected to the internet, and functioning normally.



Status LED

Condition Status	LED Color	Fios Extender
Normal	WHITE	Normal operation (solid) Fios Extender is booting (fast blink)
	BLUE	Pairing mode (slow blink) Pairing successful (solid)
	GREEN	Wi-Fi has been turned off (solid)
Issue(s)	YELLOW	No internet connection (solid) Extender is too far from the Router. Poor backhaul signal (slow blink) Extender is too close to the Router. Poor Wi-Fi coverage (fast blink)
	RED	Hardware/System failure detected (solid) Overheating (fast blink) Pairing Failure (slow blink)
Power	OFF	Power off

Please refer to section 5.0 for details on the rear LEDs.

1.3b/ REAR PANEL

The rear panel of your Fios Extender has a label that contains important information about your device, including the default settings for the Fios Extender's Wi-Fi network name (SSID), Wi-Fi password (WPA2 key), local URL for accessing the Fios Extender's administrative pages, and administrator password. The label also contains a QR code that you can scan with your smartphone, tablet, or other camera-equipped Wi-Fi device to allow you to automatically connect your device to your Wi-Fi network without typing in a password (requires a QR code reading app with support for Wi-Fi QR codes).



The rear panel has three ports; F-type coax and Ethernet LAN [two]. The rear panel also includes a DC power jack and a reset button.

- **Reset Button** - allows you to reset your Fios Extender to the factory default settings. To perform a soft reboot, press and hold the button for at least three seconds. To reset your Fios Extender to the factory default settings, press and hold the button for at least ten seconds.
- **Power** - connects your Fios Extender to an electrical wall outlet using the supplied power adapter.

***Warning:** The included power adapter is for office use only, supporting voltages from 105-125 voltage in AC. Do not use in environments with greater than 125 voltage in AC.*

1.3c/ MOUNTING THE FIOS EXTENDER TO A WALL


For optimum performance, the Fios Extender is designed to stand in a vertical upright position. Verizon does not recommend wall mounting the Fios Extender. However, if you wish to mount your Fios Extender, you can purchase a wall mount bracket from the Verizon Fios Accessories Store at verizon.com/smallbusiness/accessories/networking-wifi/

To mount your Fios Extender to a wall:

1. You may use the wall-mount template sheet for positioning the Fios Extender.

GETTING TO KNOW YOUR FIOS EXTENDER

2. Mark the mounting holes using the template sheet as shown below.



3. Drive two screws into the wall. Leave the screws extended about 0.2 inches from the wall.
4. Verify the screws are positioned correctly by placing the wall bracket on the screws. Then remove the wall bracket from the wall.



5. There are two mounting slots located on the bottom of the Fios Extender. It allows you to securely attach your Extender to the wall. Align the slots with the wall mount bracket.



GETTING TO KNOW YOUR FIOS EXTENDER

6. Attach the Extender to the wall mount bracket through an easy twist and lock action.



7. Align the wall mount bracket with the attached Extender to the screws, then slide the bracket down until it locks in place.



8. To secure the bracket, place one screw into the small hole of the bracket and tighten the screw into your wall.



Note: To release the lock, twist the Fios Extender counter-clockwise and press down on the small clip on the bottom of the bracket.



02 /

CONNECTING YOUR FIOS EXTENDER

2.0 Setting up Your Fios Extender

2.1 Main Screen

Connecting your Fios Extender and accessing its web-based User Interface (UI) are both simple procedures.

Accessing the UI may vary slightly, depending on your device's operating system and web browser.


SETTING UP YOUR FIOS EXTENDER

2.0/ SETTING UP YOUR FIOS EXTENDER

Note: Using a wired backhaul, the Fios Extender can be placed at a location distant from the Fios Router, and positioned for optimum coverage. Using Wi-Fi backhaul, performance can be slower and the distance from the Router will be determined by the reach of Wi-Fi from the Fios Router, the materials in the office, and neighboring Wi-Fi traffic. Wi-Fi backhaul is effective and convenient for Wi-Fi configuration, but based on Wi-Fi interference characteristics, does not perform as well as a wired connection.

2.0a/ WIRED INSTALLATION

- A. Connect the Fios Router to a coax outlet. (If the coax outlet is already in use, use the coax splitter included in the box.)
- B. Connect the Fios Extender to a coax outlet - ideally in an area with spotty Wi-Fi coverage.
- C. Connect the power cords from the Router and Extender to an electrical outlet.




- D. After 10 minutes, the light on the Extender should turn solid white, indicating the connection is complete.

Note: If office is wired for Ethernet, follow same steps as above using an Ethernet cable instead of a coax cable.

2.0b/ WI-FI INSTALLATION

1. Place the Fios Extender directly next to the Fios Router.
2. Take the Ethernet cable from the packaging and connect one end to the yellow port on the Router and the other end to the yellow port on the Extender.
3. Connect the power cord of the Extender to an electrical outlet.



SETTING UP YOUR FIOS EXTENDER

4. After 10 minutes, the light on the Extender should turn solid white, indicating the connection is complete.
5. Unplug and move the Extender to an area between the Router and an area with spotty Wi-Fi coverage. Once the Extender is plugged in, the light should turn solid white again within a few minutes.

You're all set! Your devices will automatically connect to your Wi-Fi network, there is nothing more to do.

***Note:** The Fios Extender has a Wi-Fi Name/Password that is different from the Fios Router. When the Extender connects to the Router via Coax, Ethernet, or Wi-Fi, the Extender is assigned the Wi-Fi Name/Password of the Router. At this time, the Extender doesn't have the ability to use the Wi-Fi Name/Password on the rear label and only uses the same Wi-Fi Name/Password as the Router.*




2.1/ MAIN SCREEN

2.1a/ Login

1. Open a web browser on the device connected to your Fios Extender network.
2. In the browser address field (URL), enter the Extender's IP address found in the UI of the Fios Router, then press the **Enter** key on your keyboard.

Note: The IP address of the Fios Extender was assigned by the Fios Router if the Extender connects to the Router.



3. Enter the password that is printed next to the Admin Password on the label on the rear of your Fios Extender.

Sign in

Username
admin

Password

Show Password

Sign in

Help


Take Control with the My Fios app >
My Verizon Account >
Watch TV Online >
Manage Voice Features on My Verizon >
Extender Support >
Verizon Help >
User Guide >



Note: The Fios Extender has an admin password that is different from the Fios Router. When the Extender connects to the Router via Coax, Ethernet, or Wi-Fi, the extender is assigned the password of the Router. At this time, the Extender doesn't have the ability to use the admin password on the rear label and only uses the same password as the Router.

MAIN SCREEN

When you log into your Fios Extender, the dashboard main page displays the main navigation menu of connection status, Wi-Fi settings, network settings and advanced quick links.



2.1b/ MENU

The main menu contains the following configuration options and chapters:

- Status - this chapter
- Wi-Fi - Chapter 3
- Network status - displayed on the graphical user interface (UI) of the Fios Router
- Advanced - Chapter 4

2.1c/ STATUS

Fios Extender Status

This section displays product model number, device FCC ID, firmware version number, device IP information, and the status of your Fios Extender's Wi-Fi connection.

The screenshot shows the 'Status' page of a Fios Extender. On the left is a navigation menu with 'Home', 'Status', 'Wi-Fi', 'Network', and 'Advanced'. The main content area is titled 'Wi-Fi Status' and 'Product Information'. It displays two Wi-Fi configurations: 2.4 GHz and 5 GHz. At the bottom, there is a 'Close' button and an 'Automatic Refresh on' toggle with a 'Refresh' button.

Wi-Fi Status	
Wi-Fi Band:	2.4 GHz Wi-Fi (B+G+N)
Wi-Fi Radio:	Enabled
Wi-Fi SSID:	Fios-7zEK4
Wi-Fi Security:	WPA2
Wi-Fi Channel:	Auto,6
Wi-Fi MAC:	B8:F8:53:84:E6:6B
Associated Clients:	0
Wi-Fi Band:	5 GHz 1Wi-Fi (A+N+AC+AX)
Wi-Fi Radio:	Enabled
Wi-Fi SSID:	Fios-7zEK4
Wi-Fi Security:	WPA2
Wi-Fi Channel:	Auto,120
Wi-Fi MAC:	62:18:53:84:e6:6e
Associated Clients:	0

Close Automatic Refresh on > Refresh >

The screenshot shows the 'Status' page of a Fios Extender, focusing on the 'Product Information' section. The navigation menu is the same as in the previous screenshot. The main content area is titled 'Product Information' and displays various device details. At the bottom, there is a 'Close' button and an 'Automatic Refresh on' toggle with a 'Refresh' button.

Product Information	
Firmware Version:	3.0.0.10-eng0
Hardware Version:	1102
Model Name:	ES200
Serial Number:	E30120071800005
Backhaul Type:	Ethernet
MAC Address:	b8:f8:53:84:e6:68
System Up Time:	0:08:04
IPv4 Address:	192.168.1.100
Subnet Mask:	255.255.255.0
Default Gateway:	192.168.1.1

Close Automatic Refresh on > Refresh >

MAIN SCREEN

CONNECTING A WI-FI DEVICE USING WPS

Wi-Fi Protected Setup (WPS) is an easier way for many devices to set up a secure Wi-Fi network connection. Instead of manually entering passwords or multiple keys on each Wi-Fi client, such as a laptop, printer, or external hard drive, your Fios Extender creates a secure Wi-Fi network.

In most cases, this only requires the pressing of two buttons – one on your Fios Extender and one on the Wi-Fi client. This could be either a built-in button or one on a compatible Wi-Fi adapter/card, or a virtual button in software. Once completed, this allows Wi-Fi clients to join your Wi-Fi network.

To initialize the WPS process, you can either press and hold the unified button located on the front of your Fios Extender for more than two seconds or use the UI and press the on-screen button.

You can easily add Wi-Fi devices to your Wi-Fi network using the WPS option if your Wi-Fi device supports the WPS feature.

To access WPS using the user interface:

1. From the main menu, select **Wi-Fi** settings, then select **Wi-Fi Protected Setup (WPS)**.

Home
Status
Wi-Fi
Network
Advanced

Basic Settings Advanced Settings Tri-band Settings Channel Settings Guest Network IoT Network

Wi-Fi Protected Setup (WPS)

Wi-Fi Protected Setup is an easy way to add Wi-Fi devices to your network. To use this feature, your Wi-Fi client device needs to support WPS.

Warning: Wi-Fi devices may briefly lose connectivity when turning WPS ON or OFF.

Wi-Fi Protected Setup: On Off

You have two alternate methods to add a Wi-Fi device to your network using WPS:

1. Push button configuration (preferred)
If your client device has a WPS button, press it and then click the button below to start WPS registration.

WPS

2. PIN enrollment:
If your client device has a WPS PIN, enter that number below (usually found on a sticker on the back of the device) and click "Register":

Client WPS PIN:

Register

Alternatively, if your client supports it, enter the extender's PIN into the client device.

Enable extender's PIN 08582769

2. Enable the protected setup by moving the selector to **On**.
3. Use one of the following methods:
 - If your Wi-Fi client device has a WPS button, press the unified button on your Fios Extender for more than two seconds, then click the WPS button on your Wi-Fi device (client) to start the WPS registration process.
 - If your client device has a WPS PIN, locate the PIN printed on the client's label or in the client documentation. Enter the PIN number in the **Client WPS PIN** field. The **Client WPS PIN** field is located in the section **2 - PIN enrollment** on the user interface.
 - Click **Register**.
 - Alternatively, you can enter the Fios Extender's PIN shown on this screen into the WPS user interface of your device, if this PIN mode is supported by your Wi-Fi device.

MAIN SCREEN

4. After pressing the unified button (WPS) on your Fios Extender, you have two minutes to press the WPS button on the client device before the WPS session times out.

When the unified button (WPS) on your Fios Extender is pressed, the Status LED on the front of your Fios Extender begins flashing blue. The flashing continues until WPS pairing to the client device completes successfully. At this time, the Status LED turns solid blue.

If WPS fails to establish a connection to a Wi-Fi client device within two minutes, the Status LED on your Fios Extender flashes red for two minutes to indicate the WPS pairing process was unsuccessful. After flashing red, the light returns to solid white to indicate that Wi-Fi is on.

Note: *Wi-Fi Protected Setup (WPS) cannot be used if WPA3 security is enabled or SSID broadcast is disabled or if MAC address authentication is enabled with an empty white list.*

03 /

WI-FI SETTINGS

- 3.0** Overview
- 3.1** Wi-Fi Status
- 3.2** Basic Settings
- 3.3** Advanced Settings
- 3.4** Tri-band Settings
- 3.5** Channel Settings
- 3.6** Guest Network
- 3.7** IoT Network

Wi-Fi networking enables you to free yourself from wires, making your devices more accessible and easier to use.

You can create a Wi-Fi network, including accessing and configuring Wi-Fi security options.

OVERVIEW

3.0/ OVERVIEW

Your Fios Extender provides you with Wi-Fi connectivity using the 802.11a, b, g, n, ac or ax standards. These are the most common Wi-Fi standards.

802.11b has a maximum data rate of 11 Mbps, 802.11a, and 802.11g have a maximum data rate of 54 Mbps, 802.11n has a maximum data rate of 600 Mbps, 802.11ac has a maximum data rate of 1.73 Gbps, and 802.11ax has a maximum data rate of 4.8 Gbps.

802.11b and g standards operate in the 2.4 GHz range. 802.11ac operates in the 5 GHz range. 802.11n and ax operates in both the 2.4 GHz and 5 GHz ranges.


***Note:** 802.11a, 802.11b are legacy modes and are not recommended. Even one such device connected to the network will slow your entire Wi-Fi network.*

3.1/ WI-FI STATUS

Use the Wi-Fi status feature to view the status of your Extender's Wi-Fi network.

3.2/ BASIC SETTINGS

You can view the basic security settings for either 2.4 GHz or 5 GHz of your Wi-Fi network.




To view the basic radio, SSID and security settings:

Select Wi-Fi from the left pane, and then click **Basic Settings**.

ADVANCED SETTINGS

3.3/ ADVANCED SETTINGS

You can view your advanced Wi-Fi security settings, such as SSID broadcast, Wi-Fi MAC authentication or limiting access to specific Wi-Fi devices, advanced mesh Wi-Fi options, and the Wi-Fi mode for limiting or allowing access to your Wi-Fi network based on the type of technology.



To view the advanced Wi-Fi security settings:

1. Select Wi-Fi from the left pane.
2. Click **Advanced Settings** to view the advanced Wi-Fi security settings of your Fios Extender.

BROADCAST

You can view the Extender's SSID broadcast capabilities to allow or disallow Wi-Fi devices from automatically using a broadcast SSID name to detect your Wi-Fi network.

802.11 MODE

From the 802.11 Mode section, you can view the Wi-Fi access to your network of the 2.4 GHz and 5 GHz Wi-Fi communication standard (mode) best suited or compatible with the devices you allow access to your Wi-Fi network.

The Wi-Fi mode:

- **Compatibility** – This is the default mode setting on 5 GHz, providing a good balance of performance and interoperability with existing Wi-Fi devices. 802.11a,n,ac and ax devices can connect.
- **Legacy** – This is the default mode setting on 2.4 GHz, providing broad connection support for old and new Wi-Fi devices. Only 802.11b,g and n devices can connect.
- 802.11n is available on both 2.4 GHz and 5 GHz frequencies.
- Connecting 802.11a or b devices will cause your Wi-Fi network to slow on that radio and is not recommended.
- When all changes are complete, click **Save Changes** to save the changes.

TRI-BAND SETTINGS

OTHER ADVANCED WI-FI OPTIONS

You can view additional Wi-Fi options.


Comment: Recommend leaving defaults as is unless otherwise directed.

View the following options:

- **SON Wi-Fi Enabled** - allows for smart roaming to provide reliable Wi-Fi network with full signal strength in all areas.
- **Clone settings from the router** - allows for synchronization of network settings from the router when the Extender connects to the router.
- **Transmit Power** – adjusts the power of the Wi-Fi signal.

3.4/ TRI-BAND SETTINGS

Fios Extender’s Tri-band network management allows for network congestion control and multiple devices accommodation with one 2.4GHz and two 5GHz frequency bands on your Wi-Fi network.



To view Tri-band Settings:

From the main menu, select **Wi-Fi**, then select **Tri-band Settings**.

3.5/ CHANNEL SETTINGS

You can configure the channel settings for either 2.4 GHz or 5 GHz of your Wi-Fi network.

Home

Status

Wi-Fi

Network

Advanced

Basic Settings Advanced Settings Tri-band Settings **Channel Settings** Guest Network IoT Network

Wi-Fi Protected Setup (WPS)

1. Channel

To change the channel of the frequency band at which the Extender communicates, please enter it below. Then click save changes to save your settings. On the 5GHz, the range of channels from 52-140 is excluded from manual selection.

2.4 GHz Channel: Automatic Current Channel: 6

5 GHz 1 Channel: Automatic Current Channel: 120

5 GHz 2 Channel: Automatic Current Channel: 52

Keep my channel selection during power cycle. Enable DFS Channels during Channel Scan

[View Channel History >](#)

2. Channel Width

2.4 GHz Channel Width: 20 MHz 20/40MHz

5 GHz 1 Channel Width: 80 MHz 80MHz

5 GHz 2 Channel Width: 80 MHz 80MHz

3. Channel Analyzer:

Perform an analysis of the available channels for each band. Upon completion, the best channel will be automatically selected.
Note: Manual channel selection will be removed.

[Perform New Scan >](#)

4. Channel Score:

The extender scans all available channels for a number of factors, such as the number of nearby Wi-Fi access points, their signal strength, and the interference these may cause. The extender then uses these to rank and select the best available channel on each band at the time.

2.4 GHz Channel Score

Channel	Score
1	5.5
2	0
3	0
4	0
5	0
6	6.5
7	0
8	0
9	0
10	0
11	5.5

5 GHz Channel Score

Channel	Score
36	0
40	1.5
44	1.5
48	1.5
52	1.5
56	1.5
60	1.5
64	1.5
68	1.5
72	1.5
76	1.5
80	1.5
84	1.5
88	1.5
92	1.5
96	1.5
100	1.5
104	1.5
108	1.5
112	1.5
116	6.5
120	6.5
124	6.5
128	6.5
132	5.5
136	5.5
140	5.5
144	5.5
148	5.5


Results from scan performed. Wait for NTP server to synchronize.

CHANNEL SETTINGS


5. Channel Analysis:

The extender scans all available channels for Access Points which are broadcasting on a channel(s) and their signal strength. Below is the most recent scan report.

2.4 GHz Channel



5 GHz Channel



On the **Channel Settings** page for either 2.4 GHz or 5 GHz, the following information displays:


- **Channel** - this is the radio channel used by the Extender and its clients to communicate with each other. The channel must be the same on the router/extender and all of its Wi-Fi clients.
 - Select the channel you want the Wi-Fi radio to use to communicate, or accept the default **Automatic** channel selection. Then the Extender will automatically assign itself a radio channel.
 - Select the **Keep my channel selection during power cycle** check box to save your channel selection when your Fios Extender is rebooted.

-
- **Channel Width** - scans and displays the channel the Wi-Fi connection is currently using.
 - **Channel Analyzer** - displays the analysis of channel availability. Click **Perform New Scan** to perform channel availability scan for the Fios Extender accommodating the best radio channel and providing the best Wi-Fi performance.
 - **Channel Score** - scans and displays a network congestion score of one to ten in each Wi-Fi channel. It can be used to determine which channels to use or to avoid. The higher score indicates less congestion in a channel.
 - **Channel Analysis** - scans and displays channel bandwidth and signal strength of available APs.

GUEST NETWORK

3.6/ GUEST NETWORK

The **Guest Network** is designed to provide internet connectivity for your guests while restricting access to your primary network and shared files. The primary network and the guest network are separated from each other through your router's firewall. **Guest Wi-Fi** can be managed using the Fios Router's web interface. If you want to enable/disable your **Guest Wi-Fi** or to change the **Guest Wi-Fi SSID (Name)** or **Password**, please log into the Fios Router's web interface for management.




To view Guest Wi-Fi:

From the main menu, select **Wi-Fi**, then select **Guest Network**.

3.7/ IOT NETWORK

The **IoT Network** is designed to provide an easier setup experience for your Internet of Things (IoT) devices which benefit from connecting to the 2.4 Ghz band while keeping your Primary Network settings unchanged. IoT devices and Primary devices can communicate unrestricted. IoT Wi-Fi can be managed using the Fios Router's web interface. If you want to enable/disable your **IoT Wi-Fi** or to change the **IoT Wi-Fi SSID (Name)** or **Password**, please log into the Fios Router's web interface for management.



To view IoT Network Settings:

From the main menu, select **Wi-Fi**, then select **IoT Network**.

Refer to “Connecting A Wi-Fi Device Using WPS” on page 24 for the Wi-Fi Protected Setup (WPS) setup.

04 /

CONFIGURING ADVANCED SETTINGS

- 4.0** Using Advanced Settings
- 4.1** Reboot
- 4.2** Admin Password
- 4.3** Factory Default
- 4.4** System Log
- 4.5** Advanced Log
- 4.6** DHCP Log
- 4.7** BHM Log

Advanced settings cover a wide range of sophisticated configurations for your Fios Extender's security and system logs.

USING ADVANCED SETTINGS

Caution: Many of the settings described in this section should only be configured by experienced network technicians. Changes could adversely affect the operation of your Fios Extender and local network.

4.0/ USING ADVANCED SETTINGS

You can access the following advanced settings:

- Reboot - restarts your Fios Extender.
- Admin Password - sets the password for administrator access.
- Factory Default - resets your Fios Extender to its default settings.
- System Log - view the most recent activity of your Fios Extender.
- Advanced Log - view a summary of the monitored data collected for Fios Extender.
- DHCP Log - view a list of all DHCP clients connected to your Fios Router.
- BHM Log - view a summary of the monitored backhaul modes of Fios Extender.


4.1/ REBOOT

Warning: Only select *Reboot Extender* if instructed to do so by Verizon support.

You can reboot your Fios Extender using the Reboot feature. Refer to 1.3b/ REAR PANEL for power reset button option.

To reboot your Fios Extender using the user interface:

1. Select **Reboot** in the **Advanced** section.



2. Click **Reboot** button on the screen. Your Extender will reboot. This may take up to a minute.
3. To access your Fios Extender user interface, refresh your web browser.
4. After the front panel Status LED turns solid white, you will automatically be sent to the web browser login page.


ADMIN PASSWORD

4.2/ ADMIN PASSWORD

The Fios Extender clones the **Admin Password** of the Fios Router. Use the **Admin Password** of the Fios Router for managing your Extender settings. If you want to change your password, please log in the Fios Router's web interface and go to **Advanced/Utilities/Users** page to make changes.

To view the Admin Password:

Select **Admin Password** in the **Advanced** section.



The screenshot shows the web interface for configuring the Admin Password. On the left is a navigation menu with options: Home, Status, Wi-Fi, Network, and Advanced (which is highlighted with a red bar). The main content area has a breadcrumb trail: Reboot, Admin Password (underlined), Factory Default, and NEXT >. Below the breadcrumb is the title 'Admin Password' and a description: 'An admin password prevents outsiders from accessing the Fios Extender firmware settings. After creating a password, you will need to enter every time you access the Fios Extender.' There is a tip icon and text: 'Tips for creating secure passwords'. A numbered instruction reads: '1. Enter the admin username and password'. Below this are three input fields: 'Admin Username:' with the value 'admin', 'Admin Password:' with an empty field, and 'Re-Type Admin Password:' with an empty field. A second instruction reads: '2. Click "Save Changes" to save your changes.' At the bottom is a 'Save Changes' button.

4.3/ FACTORY DEFAULT

You can restore the configuration settings to the factory default settings for your Fios Extender. Restoring the default settings erases the current configuration, including user defined settings and network connections.

To restore your Fios Extender's factory default settings:

1. Select **Factory Default** in the **Advanced** section.



2. Click **Restore Default Settings** button. The factory default settings are applied and your Fios Extender restarts. Once complete, the Login page for the First Time Easy Setup Wizard displays.


SYSTEM LOG

4.4/ SYSTEM LOG

System Log provides a view of the most recent activity of your Fios Extender.

To view the system log:


1. Click **NEXT** on the **Advanced** page and select **System Log**.



The screenshot shows the 'System Log' page. On the left is a navigation menu with 'Home', 'Status', 'Wi-Fi', 'Network', and 'Advanced' (highlighted). The main content area has tabs for 'System Log', 'Advanced Log', 'DHCP Log', and 'BHM Log'. Below the tabs are buttons for 'View options', 'Close', 'Clear log', 'Save log', and 'Refresh'. A table displays log entries with columns for Time, Event-Type, Log Level, and Details.

Time	Event-Type	Log Level	Details
2019 Aug 15 13:37:09	arc_ntpd daemon	info	[NTP:6][SYS] Failed got the time, would retry after 30 sec
2019 Aug 15 13:36:39	arc_ntpd daemon	info	[NTP:6][SYS] Failed got the time, would retry after 30 sec
2019 Aug 15 13:36:09	arc_ntpd daemon	info	[NTP:6][SYS] Failed got the time, would retry after 30 sec
2019 Aug 15 13:35:39	arc_ntpd daemon	info	[NTP:6][SYS] Failed got the time, would retry after 30 sec
2019 Aug 15 13:35:09	arc_ntpd daemon	info	[NTP:6][SYS] Failed got the time, would retry after 30 sec
2019 Aug 15 13:34:39	arc_ntpd daemon	info	[NTP:6][SYS] Failed got the time, would retry after 30 sec
2019 Aug 15 13:34:09	arc_ntpd daemon	info	[NTP:6][SYS] Failed got the time, would retry after 30 sec
2019 Aug 15 13:33:39	arc_ntpd daemon	info	[NTP:6][SYS] Failed got the time, would retry after 30 sec

2. To view a specific time of log event, click on the **View options** button.



The screenshot shows the 'Log Viewing Options' dialog box. It has radio buttons for 'Past Day', 'Past Week', and 'Custom Range' (selected). Below are 'Start' and 'End' time pickers with dropdowns for month, day, hour, and AM/PM. 'OK' and 'Cancel' buttons are at the bottom.

3. To refresh the page, click **Refresh**.
4. To save the log information, click **Save log**.

4.5/ ADVANCED LOG

You can view a summary of the monitored data collected for your Fios Extender.

To view your Fios Extender's full system status and traffic monitoring data:

1. Select **Advanced Log** in the **Advanced** section.

Time	Event-Type	Log Level	Details
2019 Aug 15 11:25:18	util_torch	info	[WiFi6][ADV] 5GHz High Band change channel from CH161 to CH149
2019 Aug 15 11:25:17	util_torch	info	[WiFi6][ADV] 5GHz Low Band change channel from CH36 to CH44.
2019 Aug 15 11:25:15	util_torch	info	[WiFi6][ADV] 2.4GHz Band change channel from CH1 to CH11.
2019 Aug 15 11:55:24	util_torch	info	[WiFi6][ADV] 5GHz Low Band change channel from CH44 to CH36.
2019 Aug 15 11:25:18	util_torch	info	[WiFi6][ADV] 5GHz High Band change channel from CH149 to CH161
2019 Aug 15 11:25:16	util_torch	info	[WiFi6][ADV] 2.4GHz Band change channel from CH11 to CH1.
2019 Aug 15 11:25:16	util_torch	info	[WiFi6][ADV] 5GHz Low Band change channel from CH40 to CH44.
2019 Aug 15 11:25:14	util_torch	info	[WiFi6][ADV] 2.4GHz Band change channel from CH1 to CH11.
2019 Aug 15 11:26:32	util_torch	info	[WiFi6][ADV] 5GHz Low Band change channel from CH44 to CH40.

2. To view a specific time of log event, click on the **View options** button.
3. To refresh the page, click **Refresh**.
4. To save the log information, click **Save log**.


DHCP LOG

4.6/ DHCP LOG

You can view a list of the connected DHCP clients on your network.

To view a list of the connected DHCP clients *status*:

1. Select **DHCP Log** in the **Advanced** section.



The screenshot shows a web interface with a sidebar on the left containing menu items: Home, Status, Wi-Fi, Network, and Advanced (highlighted with a red bar). The main content area has a breadcrumb trail: PREV > System Log > Advanced Log > DHCP Log > BHM Log. Below the breadcrumb is a 'View options' button and a row of controls: Close >, Save log >, and Refresh >. The main area contains a table with the following data:

Time	Event-Type	Log Level	Details
2019 Aug 15 11:20:33	dhclient	info	[DHCP.6][WDHCP] bound to 192.168.1.152 --renewal in 43197 seconds.
2019 Aug 15 11:20:29	dhclient	info	[DHCP.6][WDHCP] DHCPACK from 192.168.1.1
2019 Aug 15 11:20:29	dhclient	info	[DHCP.6][WDHCP] DHCPREQUEST on br0 to 255.255.255.255 port 67
2019 Aug 15 11:20:29	dhclient	info	[DHCP.6][WDHCP] DHCPOFFER from br0 192.168.1.1
2019 Aug 15 11:20:28	dhclient	info	[DHCP.6][WDHCP] DHCPDISCOVER on br0 to 255.255.255.255 port 67 interval 3
2019 Aug 15 11:20:21	dhclient	info	[DHCP.6][WDHCP] bound to 192.168.1.152 --renewal in 43197 seconds.
2019 Aug 15 11:20:18	dhclient	info	[DHCP.6][WDHCP] DHCPACK from 192.168.1.1
2019 Aug 15 11:20:18	dhclient	info	[DHCP.6][WDHCP] DHCPREQUEST on br0 to 255.255.255.255 port 67


2. To view a specific time of log event, click on the **View options** button.
3. To refresh the page, click **Refresh**.
4. To save the log information, click **Save log**.

4.7/ BHM LOG

You can view a summary of the BHM (backhaul modes: Ethernet, coax and Wi-Fi) status of your Fios Extender.

To view the backhaul modes log:

1. Select **BHM Log** in the **Advanced** section.



The screenshot shows a web interface with a sidebar on the left containing navigation options: Home, Status, Wi-Fi, Network, and Advanced (highlighted with a red bar). The main content area is titled 'PREV > System Log Advanced Log DHCP Log BHM Log'. Below the title are buttons for 'View options', 'Close >', 'Clear log >', 'Save log >', and 'Refresh >'. The main content is a table with the following data:

Time	Event-Type	Log Level	Details
2019 Aug 15 13:48:40	BHM	notice	[BHM.6] [BHM] arc_bhm_check_dhcp_response_thread(1949) > +{134MBH_INTERFACE_TABLE[1]downlink_flag_1, stp_learning_count: 4
2019 Aug 15 13:48:40	BHM	notice	[BHM.5] [BHM] check_led_related_thread(3960) > ARC_EX_WAN_TYPE = done
2019 Aug 15 13:48:37	BHM	notice	[BHM.6] [BHM] arc_bhm_check_dhcp_response_thread(1949) > +{134MBH_INTERFACE_TABLE[1]downlink_flag_1, stp_learning_count: 4
2019 Aug 15 13:48:37	BHM	warning	[BHM.4] [BHM] arc_bhm_check_dhcp_response_thread(1967) > +{132MUPLINK_TYPE: dox000, ARC_EX_BH_IND: eth0, IPADDR: 192.168.1.152, ip_reset: 0
2019 Aug 15 13:48:37	BHM	notice	[BHM.5] [BHM] check_led_related_thread(3960) > ARC_EX_WAN_TYPE = done
2019 Aug 15 13:48:36	BHM	notice	[BHM.6] [BHM] check_internet_connection_thread(3636) > +{133mch_packet_loss_rate = 0
2019 Aug 15 13:48:34	BHM	notice	[BHM.5] [BHM] arc_bhm_check_dhcp_response_thread(1949) > +{134MBH_INTERFACE_TABLE[1]downlink_flag_1, stp_learning_count: 4

2. To view a specific time of log event, click on the **View options** button.
3. To refresh the page, click **Refresh**.
4. To save the log information, click **Save log**.

05 /

TROUBLE SHOOTING

5.0 Troubleshooting Tips

5.1 Frequently Asked Questions

This chapter lists solutions for issues that may be encountered while using your Fios Extender as well as frequently asked questions.

Although the majority of the Fios Extender's LAN and internet connectivity is automatic and transparent, if an issue does occur accessing the internet (e.g. complete loss of connectivity, inability to access services, etc.), you may need to take additional steps to resolve the problem.

TROUBLESHOOTING TIPS

Note: The advanced settings should only be configured by experienced network technicians to avoid adversely affecting the operation of your Fios Extender and your local network.

5.0/ TROUBLESHOOTING TIPS

5.0a/ IF YOU ARE UNABLE TO CONNECT TO THE INTERNET:

- The first thing to check is whether your Fios Extender is powered on and is connected to the Fios Router. Check the Status LED on the front of the Fios Extender. Be sure to refer to the “1.3a/ FRONT PANEL” on page 8 to determine status of the Fios Extender. Check the WAN cable (Ethernet or coaxial) connecting your Fios Router to the internet to make sure it is properly connected on both ends.
- If the prior tips do not resolve your connection issue, try restarting (rebooting) the Fios Extender by manually pressing the ‘red’ reset button on the rear panel of the Fios Extender for 2-4 seconds (the Status LED should go off) to begin rebooting your Fios Extender. Your Fios Extender will begin rebooting and will return to service in 3 - 5 minutes depending on your network connection. Check Status LED and if it is solid white, try again to access the internet.
- If rebooting your Fios Extender does not resolve your connection issue, try power cycling the Extender by unplugging the power cable from the adapter or the wall and wait 2 minutes. During the 2 min. wait period, also power cycle the network device (e.g. the computer, tablet, etc.) and then plug the power cable back into the Fios Extender. After 3-5 minutes, recheck the Status LED and try again to access the internet.

5.0b/ IF YOU ARE UNABLE TO CONNECT TO YOUR FIOS EXTENDER USING WI-FI:

- Be sure your Wi-Fi device is within range of your Fios Extender; move it closer to see if your connection improves.
- Check your network device's Wi-Fi settings to be sure your device's Wi-Fi is on (enabled) and that you have the correct Wi-Fi network and password (if using a Wi-Fi password) as configured on your Fios Extender.
- Be sure you are connecting to the correct Wi-Fi network; check to be sure you are using your Fios Extender's SSID. In some cases, if using a Wi-Fi password, you may need to enter the Wi-Fi password into your network device again to be sure your device accepts the password.
- Check to be sure you are running the latest software for your network device.
- Try turning your network device's Wi-Fi off and on, and try to connect.
- If you have made any changes in your network settings and turning your network device's Wi-Fi off and on does not help, try to restart your network device.
- You may need to turn the Wi-Fi settings from on to off, and back to on again and apply the changes.
- If you are still unable to access your Fios Extender, you may need to try connecting to the Extender using another network device. If the issue goes away with another network device, the issue is likely with that individual network device's configuration.

TROUBLESHOOTING TIPS

5.0c/ ACCESSING YOUR FIOS EXTENDER IF YOU ARE LOCKED OUT

- If your Fios Extender connection is lost while making configuration changes, a setting that locks access to your Fios Extender's UI may have inadvertently been activated.

The common ways to lock access to your Fios Extender are:

- Scheduler - If a schedule has been created that applies to the computer over the connection being used, your Fios Extender will not be accessible during the times set in the schedule.
- Access Control - If the access control setting for the computer is set to block the computer, access to your Fios Extender is denied.

To gain access, restore the default settings to your Extender.

5.0d/ RESTORING YOUR FIOS EXTENDER'S DEFAULT SETTINGS

There are two ways to restore your Fios Extender's default settings. It is important to note that after performing either procedure, all previously saved settings on your Fios Extender will be lost.

- Using the tip of a ballpoint pen or pencil, press and hold the Reset button on the back of your Fios Extender for at least ten seconds.

- Access the UI and navigate to the Advanced Settings page. Select Factory Default option. Click the Restore Default Settings button. For additional details, refer to the section 4.3/ Factory Default section of this guide.

Note: If you reset or reboot your Fios Extender, you may also need to disconnect your Fios Extender's power supply for a few minutes (3 or more) and then reconnect the power cable. However, in order to provide full synchronization to the coaxial network, disconnecting and reconnecting the power may be required.

5.0e/ LAN CONNECTION FAILURE

To troubleshoot a LAN connection failure:

- Verify your Fios Extender is properly installed, LAN connections are correct, and that the Fios Extender and communicating network devices are all powered on.
- Confirm that the computer and Fios Extender are both on the same network segment.

If unsure, let the computer get the IP address automatically by initiating the DHCP function, then verify the computer is using an IP address within the default range of 192.168.1.2 through 192.168.1.254. If the computer is not using an IP address within the correct IP range, it will not connect to your Fios Extender.

- Verify the subnet mask address is set to 255.255.255.0.

TROUBLESHOOTING TIPS

5.0f/ TIMEOUT ERROR OCCURS WHEN ENTERING THE URL OR IP ADDRESS

Verify the following:

- All computers are working properly.
- IP settings are correct.
- Fios Extender is on and connected properly.

For connections experiencing lag or a slow response:

- Check for other devices on the network utilizing large portions of the bandwidth and if possible temporarily stop their current utilization and recheck the connection.
- If lag still exists, clear the cache on the computer and if still needed, unplug the Ethernet cable or disable the Wi-Fi connection to the computer experiencing the slow connection and then reconnect or enable the Wi-Fi connection and try the connection again.

In rare cases you may also need to:

- Unplug the Ethernet cable to Fios Extender and restart the Fios Extender, wait 1-2 mins. and insert the Ethernet cable again.
- Under limited circumstances you may use a port forwarding configuration on the Fios Router, based on the application you are using (refer to Verizon's support online help for more details).

5.0g/ FRONT UNIFIED BUTTON

The front panel's Unified Button allows quick access to the Wi-Fi Protected Setup (WPS) feature and handset paging/pairing mode. In addition, the Unified Button provides a visual display of the Fios Extender's current condition. Refer to the chart below for details.

Condition Status	LED Color	Fios Extender
Normal	WHITE	Normal operation (solid) Router is booting. (fast blink)
	BLUE	Pairing mode (slow blink) Pairing successful (solid)
	GREEN	Wi-Fi has been turned off. (solid)
Issue(s)	YELLOW	No internet connection (solid) Extender is too far from the Router. Poor backhaul signal (slow blink) Extender is too close to the Router. Poor Wi-Fi coverage (fast blink)
	RED	Hardware/System failure detected (solid) Overheating (fast blink) Pairing Failure (slow blink)
Power	OFF	Power off

TROUBLESHOOTING TIPS

5.0h/ REAR LIGHTED INDICATORS

Flash Speed

- Slow flash – Two times per second
- Fast flash – Four times per second

LAN Ethernet – Upper LED

- Unlit – Indicates no 1 Gbps link
- Solid green – Indicates 1 Gbps link
- Fast flash green – Indicates LAN activity. The traffic can be in either direction.

LAN Ethernet – Lower LED

- Unlit – Indicates no 10/100/1000 Mbps link
- Solid green – Indicates 10/100/1000 Mbps link

LAN Coax

- Unlit – Indicates no MoCA network connection to the device
- Solid green – Indicates network link

5.1/ FREQUENTLY ASKED QUESTIONS

5.1a/ I'VE RUN OUT OF ETHERNET PORTS ON MY FIOS EXTENDER. HOW DO I ADD MORE COMPUTERS OR DEVICES?

Plugging in an Ethernet hub or switch expands the number of ports on your Fios Extender.

- Run a straight-through Ethernet cable from the Uplink port of the new hub to the Fios Extender.

Use a crossover cable if there is no Uplink port/switch on your hub, to connect to the Fios Extender.

- Remove an existing device from the yellow Ethernet port on your Fios Extender and use that port.

5.1b/ HOW DO I CHANGE THE PASSWORD ON MY FIOS EXTENDER UI?

To change the password:

1. On the main screen, select **Advanced**, then select **Admin Password**.
2. Enter the user name and set a new password.

FREQUENTLY ASKED QUESTIONS

5.1c/ IS THE WI-FI OPTION ON BY DEFAULT ON MY FIOS EXTENDER?

Yes, your Fios Extender's Wi-Fi option is activated out of the box.

5.1d/ IS THE WI-FI SECURITY ON BY DEFAULT WHEN THE WI-FI OPTION IS ACTIVATED?

Yes, with the unique WPA2 (Wi-Fi Protected Access II) key that is printed on the sticker on the rear panel of your Fios Extender.

5.1e/ ARE MY FIOS EXTENDER'S ETHERNET PORTS AUTO-SENSING?

Yes. Either a straight-through or crossover Ethernet cable can be used.

5.1f/ CAN I USE AN OLDER WI-FI DEVICE TO CONNECT TO MY FIOS EXTENDER?

Yes, your Fios Extender can interface with 802.11a, b, g, n, ac or ax devices. Your Fios Extender also can be setup to handle only n Wi-Fi cards, g Wi-Fi cards, b Wi-Fi cards, or any combination of the three.

5.1g/ CAN MY WI-FI SIGNAL PASS THROUGH FLOORS, WALLS, AND GLASS?

The physical environment surrounding your Fios Extender can have a varying effect on signal strength and quality. The denser the object, such as a concrete wall compared to a plaster wall, the greater the interference. Concrete or metal reinforced structures experience a higher degree of signal loss than those made of wood, plaster, or glass.

5.1h/ HOW DO I LOCATE THE IP ADDRESS THAT MY COMPUTER IS USING?

In Windows 7 or Windows 10, click the Windows button and select Control Panel, then click View Network Status and Tasks. In the next window, click Local Area Connection. In the Local Area Network Connection Status window, click Details.

On Mac OS X, open System Preferences and click the Network icon. The IP address displays near the top of the screen.

5.1i/ I USED DHCP TO CONFIGURE MY NETWORK. DO I NEED TO RESTART MY COMPUTER TO REFRESH MY IP ADDRESS?

No. In Windows 7, Windows 10 and OSX, unplug the Ethernet cable or Wi-Fi card, then plug it back in.

FREQUENTLY ASKED QUESTIONS

5.1j/ I CANNOT ACCESS MY FIOS EXTENDER UI. WHAT SHOULD I DO?

If you cannot access the UI, verify the computer connected to your Fios Extender is set up to dynamically receive an IP address.

06 /

SPECIFICATIONS

- 6.0** General Specifications
- 6.1** LED Indicators
- 6.2** Environmental Parameters

The specifications for your Fios Extender are as follows.

This includes standards, cabling types and environmental parameters.

GENERAL SPECIFICATIONS

Note: The specifications listed in this chapter are subject to change without notice.

6.0/ GENERAL SPECIFICATIONS

Model Number: Model: E3200

Standards: IEEE 802.3x, 802.3u
IEEE 802.11a/b/g/n/ac/ax

IP: IP versions 4 and 6

MoCA LAN: 1125 – 1675 MHz
2500 Mbps

Speed: Wired LAN Ethernet:
10/100/1000 Mbps auto-sensing

Cabling Type: Ethernet 10BaseT: UTP/STP
Category 3 or 5
Ethernet 100BaseT: UTP/STP
Category 5
Ethernet 1000BaseT: UTP/STP
Category 5e

Firewall: ICSA certified

6.1/ LED INDICATORS

Front Panel:	Unified Button
Rear Panel:	LAN Coax and LAN Ethernet [2]

6.2/ ENVIRONMENTAL PARAMETERS DIMENSIONS AND WEIGHT

Fios Extender (unit only):

Size: 5.32" wide x 9.27" high x 5.94" deep

Weight: 2.50 lbs / 1.138 kg

Complete System (inc. packaging):

Size: 12.24" wide x 6.26" high x 7.09" deep

Weight: 4.00 lbs ~ 4.05 lbs / 1.81 kg ~ 1.83 kg

Power: External, 12V, 3.5A

Screws (optional): PH TP+N: 0.157" x 0.984"
Anchor PE: 0.197" x 0.984"

ENVIRONMENTAL PARAMETERS

Certifications: FCC, UL 60950-1

Operating Temperature: 5° C to 40° C (41° F to 104° F)

Storage Temperature: -5° C to 50° C (23° F to 122° F)

Operating Humidity: 5% to 85%

Storage Humidity: 5% to 93% (non-condensing)

07/

NOTICES

7.0 Regulatory Compliance Notices

This chapter lists various compliance and modification notices, as well as the NEBS requirements and GPL.

REGULATORY COMPLIANCE NOTICES

7.0/ REGULATORY COMPLIANCE NOTICES

7.0a/ Class B Equipment

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

FCC Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

RF Exposure:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 31 cm between the radiator & your body.

This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

2.4GHz operation of this product in the U.S.A. is firmware-limited to channels 1 through 11.

This device is restricted for indoor use.

REGULATORY COMPLIANCE NOTICES

7.0b/ Safety Warning:

1. The circuit of cable distribution system under consideration is TNV-1 circuit.
2. The common sides or earthed side of the circuit are connected to the screen of the coaxial cable through an antenna connector of tuner and to all accessible parts and circuits (SELV, LCC and accessible metal parts).
3. The screen of the coaxial cable is intended to be connected to earth in the building installation.

7.0c/ Alerte de sécurité:

1. Le circuit de distribution par câble considéré est le circuit TNV-1.
2. Les côtés communs ou côté terre du circuit sont connectés à l'écran du câble coaxial via un connecteur d'antenne du syntoniseur et à toutes les parties et circuits accessibles (SELV, LCC et parties métalliques accessibles).
3. L'écran du câble coaxial est destiné à être mis à la terre dans l'installation du bâtiment.

The cable distribution system should be grounded (earthed) in accordance with ANSI/NFPA 70, the National Electrical Code (NEC), in particular Section 820.93, Grounding of Outer Conductive Shield of a Coaxial Cable.

Le système de distribution par câble doit être mis à la terre conformément à ANSI / NFPA 70, Code national de l'électricité (NEC), en particulier à la section 820.93, Mise à la terre du blindage conducteur extérieur d'un câble coaxial.

7.0d/ NEBS (Network Equipment Building System) Statement

An external SPD is intended to be used with G3100/E3200.

WARNING: The intra-building ports of the equipment or subassembly is suitable for connection to intra-building or unexposed wiring or cabling only. The intra-building port(s) of the equipment or subassembly **MUST NOT** be metallicityally connected to interfaces that connect to the OSP or its wiring. These interfaces are designed for use as intra-building interfaces only (Type 4 ports as described in GR-1089) and require isolation from the exposed OSP cabling. The addition of Primary Protectors is not sufficient protection in order to connect these interfaces metallicityally to OSP wiring.

REGULATORY COMPLIANCE NOTICES

Caution: The Fios Extender must be installed inside the office. The Extender is not designed for exterior installation.

7.0e/ GENERAL PUBLIC LICENSE

This product contains certain software that is covered by open source licensing requirements. Copies of the licenses and a downloadable copy of the source code for the open source software that is used in this product are available on the following website:

<http://verizon.com/opensource/>

All open source software contained in this product is distributed **WITHOUT ANY WARRANTY**. All such software is subject to the copyrights of the authors and to the terms of the applicable licenses included in the download.

You may also obtain a copy of the source code for the open source software used in this product for a period of three years after your receipt of the product by sending a check for \$10, payable to VERIZON, to the address below:

Verizon
One Verizon Way
Basking Ridge, NJ 07920
Attn: Legal, Open Source Requests

Note: This information is provided for those who wish to edit or otherwise change such programs. You do not need a copy of any of such open source software source code to install or operate the device.