



Installing the Verizon PowerReserve VOICE BACKUP DEVICE.

1. Open the PowerReserve door by pressing the latched tab toward the unit and then pushing the tab up.
2. The PowerReserve device can be laid flat or mounted to a wall.
3. Uncoil the cable located in the center of the tray.
4. Insert 12 new D-cell alkaline batteries into the device. **DO NOT use rechargeable or Lithium batteries.**
5. Place the power switch to the OFF position.
6. Plug the power cable into the power adapter.
7. Recoil the extra cable on the top left of the tray.
8. Close the PowerReserve door.
9. Leave the unit OFF until needed during a commercial power outage.

