


Installation instructions

Exchange or add Fios® TV equipment.

fios[✓]
by verizon



Here are the items you may need for installation:

Fios® equipment

Router + power cord (You will receive one of the two router models shown).



Set-top box + power cord



Fios TV remote



Cables and connectors

(You may not need all items shown for your home setup.)

Ethernet cables (6')



Cable barrel connector (optional if wall outlet is not available)



Coax cables



Composite cables



HDMI cable



2-way splitter



Special order

Digital Adapter



CableCARD



Wait...


Before you start, unhook all of the existing TV equipment in your home.

- A. Unplug all cable and satellite TV set-top boxes.
- B. Unplug all third-party TV streaming devices.
- C. Already have Verizon Internet and not changing your router?
Then skip to Step 2.

Step 1

First, let's set up your Fios router.

Note: If you're using an existing Fios router, skip to Step 2.



Step 1A: Make the connections

- A. Connect the coax cable from your router to a wall outlet.
- B. Connect the power cord from your router to a wall outlet.
- C. Turn your router ON (this doesn't apply if you have a Fios Quantum Gateway).

Optional: If a TV will be connected to the same coax wall outlet as your router, connect a 2-way splitter.


Optional:
for a wired
Internet
setup.



Your router is activated when the lights turn green/white, which may take up to 15 minutes.




Step 1

Fios router setup continued.



Step 1B: Go wireless

- Check the label on your router for your Wireless network name and Wireless password.
- On your computer or smartphone, choose your wireless network name when it pops up.
- When asked, enter your wireless password exactly as it is on your router label.

		Default login credentials	
Please note: password letters are all lower-case			
Wireless network name (ESSID)	XXXXXXXXXXXX		
Wireless password (WPA2)	XXXXXXXXXXXXXXXXXX		
Administration URL	myfiogateway.com		
Administrator password	XXXXXXXXXX		
To reboot, press and hold the WPS button for 10 seconds.			
Online tutorials : www.verizon.com/quickguides			



Step 1C: Let's go surfing

- To verify your service is up and running, open an Internet browser and go to Activate.verizon.com.


Step 2

Next, install a set-top box on your main TV to begin your home entertainment experience.



Step 2A: Make the connections using HDMI cable (preferred)


- A. Connect the coax cable from your set-top box to a wall outlet.
- B. Connect the HDMI cable from your set-top box to your TV.
- C. Connect the power cord from your set-top box to a wall outlet.



Alternate option:

Make the connections using composite cables

TV not HDMI-compatible? No problem, connect the composite cables instead, making sure to match the cable colors to the back of the set-top box and TV.




Step 2

Set-top box installation continued.



Step 2B: Activate away

Turn on your set-top box and TV. Using your Fios TV remote, follow the on-screen instructions.



Step 3

Install additional set-top boxes to expand your TV-viewing experience.



Additional setup

If you have additional set-top boxes, install them now following the instructions in Step 2.



Step 4


If special ordered, install your Digital Adapter and/or CableCARD.



Digital Adapter

Make the connections

- A. Connect the coax cable from your Digital Adapter to a wall outlet.
- B. Connect the coax cable from your Digital Adapter to your TV.
- C. Connect the power cord from your Digital Adapter to a wall outlet.



Step 4

Digital Adapter and/or CableCARD setup continued.



Activate away

- Turn on the Digital Adapter by pressing the set-top box button on the Fios TV remote. Then turn on your TV and tune to channel 3 using the remote control that came with your TV.
- To complete activation, call 1.855.372.2181 and provide the activation code found on your Verizon customer receipt.

CableCARD

Get hooked up

Read through any instructions for your CableCARD-ready device and complete any set up.

Activate away

- When the CableCARD is inserted, follow the on-screen instructions.
- When prompted, enter the activation code on your Verizon customer receipt.
- Select which method of activation you prefer: Online at verizon.com/FiosTV/SelfInstall or by phone at 1.888.897.7499.



Need help?

Your satisfaction is important to us.



Call 1.800.Verizon (1.800.837.4966)

**To order extra remotes or cables,
visit verizon.com/FiosAccessories.**