Meet your phone.

verizon

About your phone

Setting up your phone

Your phone already has a SIM card installed.

Step 1. Remove the back cover

Hold the phone securely. Locate the cover release slot and carefully remove the cover.

Optional: Insert the microSD card If you have a microSD card, slide the microSD card into the microSD card slot with the gold contacts facing down.

Step 3. Replace the back cover

Place the cover over the back of the phone, and then press down along the edges to secure.







Step 2. Insert the battery Insert the battery, making sure the gold contacts line up. Press down gently to secure.



Para la versión en español, visite verizonwireless.com/Support

SAMSUNG Galaxy J7 V

NOTE: Devices and software are constantly evolving-the screen images and icons you see here are for reference only.

About your phone

Setting up your phone

Step 4. Charge your phone Before turning on your phone, charge it fully.

Insert the small end of the USB cable into the USB/Charger port. Insert the larger end into the charger and plug it into an outlet.



Using your phone

Turning your phone on/off To turn your phone on, press and hold the **Power/Lock** button.

Press and hold the **Power/Lock** button again to turn it off.

Locking/unlocking the screen

To turn on your screen, press the **Power/Lock** button. Then swipe up on the screen to unlock it.

To turn off your screen and prevent accidental key presses, press the **Power/Lock** button.

Copying content from your old phone For help transferring contacts, photos and other content from your old phone, visit: verizonwireless.com/Cloud. Ecui

Home screen mode

You can select one of the two modes: Easy and Standard. Instructions in this guide are written for Standard mode.

Standard mode is for users who are familiar with Android.

Easy mode is a simplified experience for the first-time smartphone user.

- Image: Settings > Easy mode.
- 2. Choose the mode you want to use and tap Done.



Learning more

? Use the Help feature to access your device user manual and other information on how to use your phone.



To open the Help app, tap Apps > Settings > Help.



≡

Download a User Guide from verizonwireless.com/Support or call 888.987.HELP (4357) to order

a copy.

Managing your account

 My Verizon Mobile app

 Manage your account, track your usage, edit account information, pay your bill and more.

 International travel

 For features and rates when outside the US, visit:

 verizonwireless.com/International.

 Image: Customer service Call 800.922.0204

 Twitter @VZWSupport

Additional information

Your wireless device and third-party services

Verizon Wireless is the mobile carrier associated with this wireless device, but many services and features offered through this device are provided by or in conjunction with third parties. Verizon Wireless is not responsible for your use of this device or any non-Verizon Wireless applications, services and products, including any personal information you choose to use, submit or share with others. Specific third-party terms and conditions, terms of use and privacy policies apply. Please review carefully all applicable terms, conditions and policies prior to using this wireless device.

Hearing aid compatibility information

This phone has been tested and rated for use with hearing aids for some of the wireless technologies that it uses. However, there may be some newer technologies that have not been tested yet for use with hearing aids. It is important to try the different features of this phone thoroughly and in different locations, using your hearing aid or cochlear implant, to determine if you hear any interfering noise. Ask your service provider or the manufacturer of this phone for information on hearing aid compatibility. If you have questions about return or exchange policies, ask your service provider or phone retailer.

WARNING: Use only charging devices and batteries that are approved by Samsung. Samsung accessories are designed for your device to maximize battery life. Using other accessories may void your warranty and may cause damage.